

Truss Boom

When lifting and lowering roof trusses, framing walls or steel beams into place, use the truss boom; available with or without a winch.

Notes:

- Truss boom with winch feature requires auxiliary hydraulics



Distributed By:



www.onesourcerental.com

Current Production Truss Booms

Ordered through JLG Aftermarket Parts or with new machine orders

LENGTH		12 ft.	12 ft. w/Winch	15 ft.
CAPACITY		2,000 lb.	2,000 lb.	2,000 lb.
PART NO.		1001099902S	1001099351	1001099901S
JLG	G6-42A SERIAL NO. 0160037722 - AFTER	•	•	•
	G9-43A SERIAL NO. 0160037671 - AFTER	•	•	•
	G10-43A	•	•	•
	G10-55A SERIAL NO. 0160037689 - AFTER	•	•	•
	G12-55A SERIAL NO. 0160037689 - AFTER	•	•	•
Skytrak	6036 SERIAL NO. 0160031200 - AFTER	•	•	•
	6042 SERIAL NO. 0160031200 - AFTER	•	•	•
	8042 SERIAL NO. 0160031235 - AFTER	•	•	•
	10042 SERIAL NO. 0160031425 - AFTER	•	•	•
	10054 SERIAL NO. 0160031255 - AFTER	•	•	•
Lull	644E-42 SERIAL NO. 0160031500 - AFTER	•	•	•
	944E-42 SERIAL NO. 0160031500 - AFTER	•	•	•
	1044C-54 SII SERIAL NO. 0160037893 - AFTER	•	•	•

NOTE: Use only JLG approved attachments with proper material handler model/attachment load capacity charts displayed in the operator's cab.
 Can't find the attachment you are looking for? Contact your JLG Aftermarket Parts representative at 1-877-JLG-LIFT or visit www.jlg.com.